

WOOD PLACES®
CENTER DRAWER MOUNTING
Installation Instructions

1. The underside of the desk tops are pre-drilled for mounting center drawers. Determine the proper placement and locate holes. **NOTE: Pilot holes need to be drilled for worksurface installations. After determining and marking the desired drawer location, drill eight (8) .094 dia. x .50 deep holes. Take care not to drill through the worksurface.**
2. Fully extend the drawer slides. Align the screw holes in the slides with the holes on the underside of the desk top.
3. Using the eight (8) #8 x .63 truss head screws (provided), install the center drawer to the desk top (Fig. 1). Do not fully tighten the screws.
4. Slide center drawer from front to back to insure proper alignment and travel before tightening the screws.
5. Tighten screws.

