


HAWORTH



Atwell

Service Instructions


Seat & Back Replacement



Tools Required




Parts




Seat & Back Removal/Replacement


1 Remove Seat



2 Remove Back



3 Reinstall Back



4 Reinstall Seat

