



**BE\_HOLD™**  
**Legs - Single/Double/Triple**  
**Installation Instructions**




**Scale 1 : 1**


**Tools Required**



**LEGS - SINGLE CABINET**










**LEGS - DOUBLE CABINET**



CUSTOMER SERVICE PHONE: 1-800-426-8562

**LEGS - TRIPLE CABINET**



CUSTOMER SERVICE PHONE: 1-800-426-8562

**HAWORTH**


E.C.O. No: 781-431

Page: 2 of 12


Part No: 6100-0134

Rev: 1

1



2



CUSTOMER SERVICE PHONE: 1-800-426-8562

**HAWORTH**


E.C.O. No: 781-431

Page: 3 of 12


Part No: 6100-0134

Rev: 1

3



4



CUSTOMER SERVICE PHONE: 1-800-426-8562

**HAWORTH**



E.C.O. No: 781-431

Page: 4 of 12

Part No: 6100-0134

Rev: 1

5



CUSTOMER SERVICE PHONE: 1-800-426-8562

**HAWORTH**

E.C.O. No: 781-431



Page: 5 of 12

Part No: 6100-0134

Rev: 1



6

(S224)



7

**NOTE: DO NOT** install screws in this step.



CUSTOMER SERVICE PHONE: 1-800-426-8562

**HAWORTH**


E.C.O. No: 781-431

Page: 6 of 12



Part No: 6100-0134

Rev: 1

8



9



CUSTOMER SERVICE PHONE: 1-800-426-8562

**HAWORTH**


E.C.O. No: 781-431

Page: 7 of 12


Part No: 6100-0134

Rev: 1

10



11



CUSTOMER SERVICE PHONE: 1-800-426-8562

**HAWORTH**

E.C.O. No: 781-431

Page: 8 of 12



Part No: 6100-0134

Rev: 1




12

NOTE: Screw (S-17) must be flush.




13



UNEVEN

EVEN



CUSTOMER SERVICE PHONE: 1-800-426-8562

**HAWORTH**





E.C.O. No: 781-431

Page: 9 of 12

Part No: 6100-0134

Rev: 1




14



15

**! IMPORTANT!**

**DO NOT ROTATE CASE ON LEGS. LIFT CASE, THEN ROTATE AND PLACE.**



CUSTOMER SERVICE PHONE: 1-800-426-8562

**HAWORTH**


E.C.O. No: 781-431

Page: 10 of 12


Part No: 6100-0134

Rev: 1

16



17



CUSTOMER SERVICE PHONE: 1-800-426-8562

**HAWORTH**

E.C.O. No: 781-431



Page: 11 of 12

Part No: 6100-0134


Rev: 1

**PULL INSTALLATION**



**1**




**2**



**DOOR HINGE INSTALLATION/REMOVAL**




**DOOR HINGE ADJUSTMENT**



**OPTIONAL: LOCK PLUG INSTALLATION**

**1**


Replace square key (R1) with round key (R2)



**2**

Install lock plug (A1)


**NOTE:** Position cam to unlocked (9:00 o'clock) position.  
**NOTE:** It may be necessary to rotate cam until lock plug engages.



**3**

Remove round key (R2) and insert square key (R1)

**NOTE:** Hold the lock plug (A1) in place with thumb while removing the control key (R2).



CUSTOMER SERVICE PHONE: 1-800-426-8562